



REMINGTON 870P SHOTGUN



REMINGTON 870P SHOTGUN



REMINGTON 870P SHOTGUN

- Introduced in 1950 by Remington Firearms
- Used in the Military and in Combat
- It became so popular
 - The Peoples Republic of China produced the Shotgun for use in their country under the make of Norinco
 - 32 Countries currently use the Remington 870 including countries like Iran.

How Many of you are familiar with this Shotgun?

REMINGTON 870P SHOTGUN



NOMENCLATURE

- ⦿ ALL Parts are Interchangeable

- ⦿ The 870 is a
 - Bottom Loading
 - Slide Ejecting Receiver
 - Tubular Magazine

NOMENCLATURE





Open the Action

- Select the Safety
- Hold the Fore-End
- Press and HOLD the Action Release
- Pull the Fore-End DOWN towards the Receiver
- The ACTION IS NOW OPEN and the BOLT is to the rear out of VIEW.



Checking the Shotgun prior to Loading

- ⦿ Check the Shotgun to make sure the SAFETY is ON
- ⦿ Look UNDER the Shotgun and Check if you can see the Magazine Tube ORANGE Follower? If so, there no rounds inside the Tube.
- ⦿ If there are rounds inside the Tube, remove them immediately!!!!
- ⦿ Open the ACTION or make sure it is OPEN
- ⦿ Visually and Physically check the CHAMBER for any rounds or obstructions.



Disassembly & Reassembly

- ◉ Point the Shotgun up in a SAFE direction!!!
- ◉ Screw and Remove the Magazine CAP
- ◉ Carefully remove the Barrel and check for obstructions inside the barrel.
- ◉ Screw the Magazine Cap back on.
- ◉ Using the Fore-End, move the action to the forward position.
- ◉ With the Safety on, pull the trigger to test the safety
- ◉ Safety OFF, place finger on the hole in the bolt and press the trigger. You should feel the firing pin strike your finger.
- ◉ Reassemble the shotgun, DO NOT OVER tighten the Magazine CAP.



Loading (PATROL READY)

- ◉ Point the Shotgun up in a SAFE Direction
- ◉ WATCH and Close the ACTION by moving the Fore-End forward, watch the bolt go forward.
- ◉ Point the Shotgun in a SAFE Direction and pull the trigger
- ◉ LOAD (4) Four Less lethal Rounds into the Magazine Tube. Count the rounds as you LOAD them and make SURE they are Less Lethal rounds!!!
- ◉ Place the Shotgun in the Shotgun Rack in the FRONT of your car.



Unloading a loaded shotgun

- Remove the Shotgun from your Vehicle Mount.
- Immediately place the SAFETY ON!!!!
- Place your 3 fingers and thumb around the Fore-End and your last finger UNDER the Fore-End and WALK the Fore-End downward SLOWLY.
- Take your free hand THUMB and push the CARRIER in towards the Bolt and move your thumb up towards the Shell inside the Magazine Tube.
- As you walk the Fore-End down, the Less Lethal Round will eject from the magazine tube and you capture it with your thumb and remove it.
- Using your left hand thumb, depress the Shell Latch and remove the remaining rounds.



INATTENTION

- ◉ INATTENTION is the one MAJOR cause of Accidental Discharges in a Shotgun and Rifle.
- ◉ You're Loading, Unloading or reloading your Shotgun while talking to somebody else or your mind is thinking of something else besides what your doing.
- ◉ LOOK and THINK about what you are doing at the time you are doing it.
- ◉ Do NOT Look around!!!
- ◉ Do NOT talk to anybody!!!
- ◉ Look at the rounds you are loading into the Shotgun.



Policy regarding Accidental Discharges

Policy 306.7 States

- Make a VERBAL Report to your Supervisor
- If On-Duty, file a written report to your Supervisor
- If Off-Duty, file a written report no later than the end of your next regular shift
- Unless otherwise directed by a Supervisor



Unloading a Chambered Round

Place the SAFETY ON



Unloading a Chambered Round

Place your 3 fingers and thumb around the Fore-End and your last finger UNDER the Fore-End and WALK the Fore-End downward SLOWLY.



Unloading a Chambered Round

- ⦿ Watch the Ejection Port while you WALK the Fore-End down and wait for the Round to appear.
- ⦿ When the Round appears to be ejecting, remove the round and STOP walking the Fore-End down.



Unloading a Chambered Round

- Take your free hand THUMB and push the CARRIER in towards the Bolt and move your thumb up towards the Shell inside the Magazine Tube.
- As you walk the Fore-End down, the Less Lethal Round will eject from the magazine tube and you capture it with your thumb and remove it.



Unloading a Chambered Round

- ⦿ Using your left hand thumb, depress the Shell Latch and remove the remaining rounds.
- ⦿ ReLoad your Shotgun 'Patrol Ready' and Place it in your vehicle.



REMINGTON 870P SHOTGUN

QUESTIONS??



REMINGTON 870P SHOTGUN





REMINGTON 870P SHOTGUN





REMINGTON 870P SHOTGUN





REMINGTON 870P SHOTGUN





REMINGTON 870P SHOTGUN





REMINGTON 870P SHOTGUN

